High Level Site Training

Elements covered

- Training explained
- How much did your last car cost?
- MHE/Pedestrian circulation pattern
- Alcohol & drugs
- Traffic flow
- Use of trucks outside
- Distance rules
- Truck speed
- Housekeeping
- Personal Protective Equipment (PPE)
- Aerosol Storage Unit (ASU)
- Dealing with leaking aerosols
- Driving rules
- Seat belts

- Condition of pallets
- Manual handling
- One point lessons
- Emergency shower & eyewash
- Validation
- <u>Reporting defects</u>
- Incident investigation
- MHE authorisation
- EQUIPMENT SPECIFIC
- Reach
- Counterbalance

Training explained

- Suitable candidate selected
- Valid MHE Medical
- Basic Training
 Refreshed every 3 years
- Site Training
 Refreshed every year
- Probationary period
 2 months
- Assessment
 Theory & Practical






How much did your last car cost?

- Compare that to the costs of our truck fleet...
- Order Picker.....£12,200
- Electric Pallet Truck.....£12,750
- Reach Truck.....£35,300
- Pyroban Reach Truck......£50,900
- L'Oréal has invested a quarter of a million pounds in trucks on this site, to give you the best equipment to work with.
- Please drive them carefully and safely!



MHE/Pedestrian circulation pattern



MHE/Pedestrian circulation pattern (ASU) Fire exit A Fire Fire exit ID Pallet consolidation area N File

MHE / PEDESTRIAN CIRCULATION PATTERN



Alcohol and drugs



- The law considers a fork lift truck to be a motor vehicle
- This means that an operator who is found to be operating a truck whilst under the influence of alcohol or drugs can be prosecuted
- Employees must not be under the influence of or suffering the effects of alcohol or drugs at any time during the working day



Traffic Flow



- One way systems
- Give way rules
- Pedestrian only areas
- Protected and designated walkways
- Trafford Park:
 - Tunnel MHE Access only





Use of trucks outside


Only Counterbalance to be used outside
Reach truck – internal truck only




Distance rules

- 2000 to 2006: more than 20% of all incidents in L'Oréal were linked to mechanical handling equipment (MHE)
- 2007: 22% of all accidents were MHE related
- Jan Aug 2008: 30% were MHE related
- Post August 2008 two serious accidents involving broken bones due to forklift operations





Truck is **stopped** Stay **1 metre** away




- Applicable to all trucks
- Includes truck to truck AND truck to pedestrian
- Responsibility of driver AND pedestrian






- Includes truck to truck AND truck to pedestrian
- Responsibility of driver AND pedestrian






Passing trucks moving in opposite direction **Drive carefully**




Slow down if required





Passing pedestrians in racking or loading bay **Sound horn Make eye contact**



- Includes pickers on foot while picking
- PEDESTRIAN has right of way



Truck speed



- The maximum speed of all trucks have been pre-set:
 - Speed limited to a maximum of 8 km/h when the forks are less than 50cm from the ground
 - Speed limited to 1.6 km/h when the forks are over 50cm from the ground
 - All loads must be transported with the forks between 15 and 20cm from the ground



Housekeeping



- Keep your truck clean and tidy at all times
- Do not place stickers on your truck
- File pre use checks neatly in the folder provided
- Do not deface or remove anything fixed to the truck



Personal protective equipment



- High visibility vests and safety shoes
 At all times in the warehouse
- Gloves
 - On all handling tasks
- Knives
 - Only approved safety knives



Aerosol storage unit (ASU)

Trained & authorised people only!

- No smoking materials
- No mobile phones
- Only specially adapted trucks and equipment
- No low level order pickers in this area

Remember! Only specially adapted trucks and Equipment in the ASU





Dealing with leaking aerosols



- Remove damaged aerosols immediately by the nearest exit (Use a fire exit if appropriate)
- Inform a Health & Safety Rep or your Supervisor

Remember:

- Aerosols are perfectly safe if handled with care
- Safe working practices are essential
- Do not take risks!
- If you are unsure about any situation then cease work and seek guidance immediately



Driving rules

- Keep to the left in aisles
- Make use of mirrors
- Obey give way and stop signs
- No parking in the cross hatched areas
- No transporting of double stacks only exception is unloading via an EPT









Driving rules

- Operate with caution & awareness near unprotected walkways
- Trafford Park:
- Obey "One way" system (aisle 80)
- Only "Low level" trucks are allowed to operate through the central racking aisle!









Driving rules



- Nobody ever said trucks should be seen and not heard
- Whenever you approach intersections and corners, give several short sharp blasts on the horn to warn of your presence




Seat belts



- All high level trucks have been fitted with seat belts
- You must wear the seat belt at all times when the truck is in motion
- You must not tamper with the seatbelt mechanism



Seat Belt



This film was captured on the CCTV at the Kalouga Warehouse in Jan 2013.

Condition of pallets


Check for:


- Loose / missing blocks
- Nails protruding
- Suitable for load
- Stringers intact





Manual handling





Manual handling

- Examine the load
- Get help or use a mechanical aid if required
- Plan the lift
- Ensure good grip
- Use grab sticks available







One point lessons

- A one point lesson (OPL) provides step by step guidance on completing a task
- They are displayed at point of use on notice boards across the site
- Familiarise yourself with the location and content of any one point lessons that relate to the operation of your truck

Remember!

Always follow the instructions provided in the One Point Lesson



Emergency shower & eye wash

Emergency shower and eye wash facilities are located in the battery charge room

Familiarise yourself with the operation of these facilities and the location of first aid stations across site







Validation

- In order to comply with corporate requirements an annual MOT is required
- This covers:
 - CE marks
 - Guards & safety features
 - Statutory inspections have been undertaken



Reporting defects

If there is a fault with your truck:

- Remove the validation tag to reveal the Do not use this equipment sign
- 2. Pass the tag to your supervisor
- 3. Provide detailed information regarding the fault.





Incident investigation

- If you have any type of incident whilst operating your truck, you must report it immediately to your supervisor
- All incidents involving MHE are treated seriously and you will be asked to participate in a Root Cause Analysis (RCA)
- You will not be permitted to operate your truck until the RCA and relevant actions have been completed



MHE authorisation

Authorisation Explained

- Issued to all powered truck operatives
- Details basic and site training expiry dates
- Includes medical expiry date
- It is your authorisation to operate equipment
 issued by your shift manager
- Keep your authorisation with you at all times when on site
- Longer term aim to develop a penalty points system to accompany authorisation





Truck Specific Training



Reach Truck



Counterbalance



Reach Truck



Site Training



Types of reach truck

- There are two types of reach truck:
 - Standard
 - Pyroban rated
- Only the pyroban rated reach truck can be used in the Aerosol Storage Unit (ASU)

Remember!

Only specially adapted trucks and Equipment in the ASU




Operation of pyroban system

Green fob

- Operates truck under normal operation
- 2 activation levels:
 - Level 1 Audible warning
 - Level 2 Truck shutdown

Red fob

- Used to re-activate truck following Level 2 shutdown
- The red fob is a restricted controlled key









- Validation Multi-Tag Displayed
- Condition of Forks
 - Check for cracks, fractures, excessive ware deformity and ensure they are equally spaced and locking pins engaged
- General cleanliness
- Battery condition
- Battery water level
- Carriage
- Mast

Check for damage, distortion and cracks

Mast Roller/Slides





Lift chains & pulleys

Check for loose or worn pins or links, chain anchors securely fixed, chain pulleys free from damage, free from ware and flat spots

- Hoses
- Wheels/Tyres
 Check bolts, cuts and missing treads
- Camera
- All truck panels secured
- Fire extinguisher

All high level trucks are fitted with fire extinguishers





- Operating position/seat Check anchor points, runners and sliders, also check for objects under the seat
- Starting procedure
- Lights
- Guards
- Seat belt
- Horn
- Display





Hydraulics

 Ensure smooth operation of all controls to full extent of travel
 Lift / reach / side shift
 Steering

Check for freedom of movement in both directions while stationary and on the move

Footbrake

Move the truck backward and forwards and test

Parking brake

Ensure the Parking brake prevents forwards & backwards movement



Access control



- Keypad operated
- "14016" or Clock card number required
- Switch machine off when not in use to prevent unauthorised use



 If the LED on the battery is flashing red (as per pre use check) the battery level is low and requires topping up



- Park truck in charging room away from doorways and close to plug point
- Wear the following PPE whilst performing the task:
 - Gloves Goggles





- Gain access to Reach battery by:
 - Bringing reach in as far as possible
 - Engage battery release lever
 - Send out reach
 - Disconnect battery





- Top up batteries using Aquajet system:
 Check water level is above black line on pump by twisting off water cap
- Ensure pipe work is free from kinks:
 - Connect the filling hose on the Aquajet to the battery coupling
 - Plug in and switch on Aquajet system







Open water valve completely

- □ Wait until spinner stops (10 15 sec.)
- Close water valve

Switch off and unplug Aquajet system

 Disconnect Coupling - can only be disconnected in "closed" position

Close access to Reach battery by:

- Reconnect battery to truck
- Bring reach back home make sure connecting cable does not get trapped
- Ensure release lever clicks in place
- Only top up battery after it is fully charged at the start of the AM shift









Addressing a pallet



- Ensure your forks are centrally positioned
- You must always extend your reach controls whilst engaging/disengaging a pallet!



Camera rules



- Reach trucks have been fitted with onboard camera monitors
- It is mandatory to use the camera at level 3 and above
- Always report any defects to your supervisor immediately

Ergonomics

- Ensure all limbs are within the confines of the truck
- Adjustable attachments for added comfort include:
- Adjustable seatbelt
- Adjustable steering column
- Adjustable seat:
 - Slide forwards & backwards
 - Backrest for added comfort

Conclusion

- Once you have qualified as a truck operator it's your responsibility to ensure your own safety and that of your colleagues and anyone else who may be affected by your actions
- Practice safe operating procedures until they become routine

Always put safety first



Any Questions?





Counterbalance



Site Training





- Validation Multi-Tag Displayed
- Condition of Forks

Check for cracks, fractures, excessive ware deformity and ensure they are equally spaced and locking pins engaged.

- General cleanliness
- Battery condition
- Battery water level OK
- Carriage
- Mast

Check for damage, distortion and cracks.

- Mast Roller/Slides
- Lift Chains & pulleys

Check for loose or worn pins or links, chain anchors securely fixed, chain pulleys free from damage, free from ware and flat spots.

- Hoses
- Wheels/Tyres

Check bolts, cuts and missing treads.

All truck panels secured





Fire extinguisher

All high level trucks are adapted with fire extinguishers.

Operating position/seat

Check anchor points, runners and sliders, also check for objects under the seat.

- Starting procedure
- Lights
- Guards
- Seat belt
- Horn
- Display
- Hydraulics

Ensure smooth operation of all controls to full extent of travel.

- Lift / Reach / side Shift
- Steering

Check for freedom of movement in both directions while stationary and on the move.

Footbrake

Move the truck backward and forwards and test.

- Handbrake
- Move the truck backward and forwards and test.
- Deadman Seat



Access Control

- Davis Darby operated
- Log off machine when not in use



Add from OPL



Restricted areas

 Counterbalance can only be used internally in designated areas and routes
 <u>Circulation plan</u>




Use in yard

- Traffic pedestrians, contractors, reversing vehicles, stand trailers
- Weather adjust speed, seek further advice in inclement conditions
- Stacking & de-stacking of pallets
- Loading & unloading of trailers
- Mandatory to use spot lights & beacon for external tasks
- Additional PPE provided when required



Travelling on slopes

The forks should face uphill if the truck is laden and downhill if the truck is unladen





Travelling on slopes

Rules on slopes

- Always travel directly up or down the slope
- Slow down approaching the door
- Sound horn approaching the doorway
- Come to a STOP before entering the warehouse
- Make a thorough check for pedestrians and MHE
- Make full use of the mirrors available







Ergonomics

- Ensure all limbs are within the confines of the truck
- Adjustable attachments for added comfort include:
- Adjustable steering column
- Adjustable seat:
 - Slide forwards & backwards
 - Backrest tilt

Conclusion

- Once you have qualified as a truck operator it's your responsibility to ensure your own safety and that of your colleagues and anyone else who may be affected by your actions
- Practice safe operating procedures until they become routine

Always put safety first



Any Questions?



