



TE transmissions training program

- Basic converter/transmission theory
- TE transmissions
- TE 13/17/32 transmissions
- APC200 controller
- TE transmission field experience



Basic connverter /transmission theory


- ◆ movie



TE transmissions

- ◆ Electronic controlled modulation
- ◆ Clutch overlap control
- ◆ Inching control

Electronic controlled modulation (E.C.M.)







Electronic controlled modulation (E.C.M.)




Modulated build up of pressure in the clutch






Modulated build up of pressure in the clutch

different modulation energy




different modulation in power






Overlap control





Electronic controlled inching


Inch speed as function of brake pedal position






Spicer Off-Highway Products Division

TE13/17 transmission







Model designation

340 E I E 13 3 XX - XX

Converter
Model Wheel Group
Converter freewheel
(optional)

specific "dash number"

Engine mount
With converter

specific ratio/drop

Electronically controlled model

numbers of gears

Model number
Transmission input rating x
100Nm



Technical specifications

Converter/Transmission Oil System

Capacity 16,5L Lines and cooler not included

Oil Type **Only** ATF Dexron III approved

viscosity at 40°C: 33 → 38 cSt

viscosity at 100°C: 7 → 8 cSt

Oil change **1000 hours**

Filtration

integral spin on change every 1000 hours

first change or after



Technical specifications

Ratios

<u>BASIC MODEL</u>	<u>SPEED</u>	<u>FWD 1st</u>	<u>REV 1st</u>	<u>FWD 2nd</u>	<u>REV 2nd</u>	<u>FWD 3rd</u>	<u>REV 3rd</u>
13310 17310	3/3	4.022	4.003	1.923	1.914	0.912	0.908



Temperature specifications

Normal operating temperature 70 - 120°C at temperature check port 71 converter out

Maximum allowed transmission temperature 120° C

Pressure specifications

Transmission regulator pressure :

25 -30 bar at 2200RPM



Clutch pressures

At 2200 RPM 24 – 29 Bar

Filter bypass

valve set at 3.9
bar

Lube pressure

In neutral 0 : 2.8-3.4 Bar at 80 l/m flow

In FWD 0 – REV 0 : 1.2-1.8 Bar at 80l/m flow

Internal leakage

Converter : 1.0 -4.0 l/m

Each range clutch : 1.5-4.5 l/m

Each directional clutch : 5.5-9.0 l/m



Safety valve

cracking pressure 7,5
bar

Converter out pressure (to cooler)

3.0 – 3.5 bar. at max stall speed



Pump flow

At 2200 RPM : 90 to 110 lpm



Electrical specifications

- Electronic controlled modulation valves (Fwd/Rev/2nd/1st-3rd).
coil resistance : $4.35 \pm 0.35 \Omega$ at 25°C [77°F].
- Total neutral and 1st/3rd range solenoid:
coil resistance : $28 \pm 2 \Omega$ at 20°C [68°F].
- Speed sensor :
 - type: magneto resistive sensor.
 - sensing distance: $1,8 \text{ mm}$ [0.07°].
 - Sensor signal: generates a square current with a fixed amplitude changing between 7 and 14 mA.



Hydraulic cooler line specifications

HYDRAULIC COOLER LINES SPECIFICATIONS.

Minimum 19 mm internal diameter for lines and fittings.


Suitable for operation from ambient to 120° C continuous operating temperature.

Must withstand 30 bar continuous pressure and 45 bar intermittent surges.

Conform SAE J1019 and SAE J517, 100RI.




EXTERNAL PLUMBING






Additional signals

- ◆ Speed sensors
 - Engine speed combined with oil temperature pick up located at pump gear
 - Turbine speed located on input gear forward
 - Drum speed located on low drum
 - Output speed located on output gear
- ◆ Pressure feedback sensor
- ◆ Oil temperature
- ◆ Converter out temperature switch



Wiring schematics



VFS = Variable Force Solenoid

Depending on input current (from 0 to 1000mA), output pressure is regulated from (6 to 0 bar)




Wiring schematics

Pin	Wire Colour	Function
1-2	Blue	VFS 2nd
3-4	Green	VFS Fwd
5-6	Yellow	VFS 3rd / 1st
7-8	Red	VFS Rev
9-10	Black	Total Neutral
11	White	Pressure switch
12	-	-
13	Orange	Solenoid 3rd / 1st
14	White	Common ground

Control valve

- ◆ Variable force solenoids (VFS)
 - VFS0 for forward
 - VFS1 for 2nd
 - VFS2 for reverse
 - VFS3 for 1st / 3rd
- ◆ Pressure reducer
- ◆ Pressure intensifiers for each VFS






Solenoid activation

Transmission Gear	Activated Solenoids	Activated VFS	Activated Clutches
Forward 3	Total neutral	Rev, 2nd	Fwd, 3rd
Forward 2	Total neutral	Rev, 1st/3rd	Fwd, 2nd
Forward 1	Total neutral, 1st/3rd	Rev, 2nd	Fwd, 1st
Neutral 1	Total neutral, 1st/3rd	Rev,Fwd, 2nd	1st
Reverse 3	Total neutral	Fwd, 2nd	Rev, 3rd
Reverse 2	Total neutral	Fwd,1st/3rd	Rev, 2nd
Reverse 1	Total neutral,1st/3rd	Fwd, 2nd	Rev, 1st

Electronic controlled modulation (E.C.M.)





Operation of transmission

The transmission is controlled by an APC200 box. This unit has a microprocessor that receives certain inputs (gear selector position, speed sensors,...), which are processed and will give output signals to the control valve.

Operation of the valve

Regulated pressure (25-30 bar) is directed to the total neutral shift spool and the pressure reducer that will decrease the pressure to 10 bar.

This reduced pressure will be used to supply the variable force solenoids(VFS), total neutral solenoid and 3rd/1st solenoid.

The VFS will give an output pressure curve from 0 to 6 bar proportional to a current from 1000 mA to 0 mA. The pressure intensifiers with a ratio of 5:1 will multiply this pressure curve so that a curve from 0 to 30 bar is available for each directional and range clutch. Between each VFS a pressure intensifier is placed and an accumulator to dampen any hydraulic vibration.

Directional selection

When a direction (forward or reverse) is selected , total neutral solenoid is activated and the required directional VFS will provide a pressure rise from 0 to 6 bar. The directional clutch is then fed with modulated pressure supplied through the pressure intensifier.



Operation of transmission

Range selection

When 1st clutch is selected, the 3rd/1st solenoid is activated and 1st/3rd VFS will provide a pressure curve from 0 to 6 bar. The pressure intensifier will multiply this pressure and will feed 1st clutch via the activated 3rd/1st spool.

When 2nd clutch is selected the 2nd VFS will provide a pressure curve from 0 to 6 bar. This pressure is fed to 2nd clutch via the pressure intensifier, at the same time 1st/3rd VFS will decrease pressure from 6 to 0 bar, thus allowing the release of 1st clutch in a controlled fashion, which will provide clutch overlap.

When 3rd clutch is selected the 3rd/1st solenoid is not activated. The 1st/3rd VFS will provide a pressure curve from 0 to 6 bar and will feed 3rd clutch via a pressure intensifier and the deactivated 3rd/1st spool. At the same time the 2nd VFS will decrease pressure from 6 to 0 bar providing the clutch overlap.

Neutral selection

When neutral is selected (1st, 2nd or 3rd), the total neutral solenoid is activated and the VFS's for forward and reverse are fed by a 1000mA current, which will result in a 0 bar output, thus providing 0 bar pressure to the forward and reverse clutch. The range clutches 1, 2 or 3 remain activated by their respective VFS.



Operation of transmission

Total neutral selection

Total neutral is only selected by the APC200 in case a severe error is detected which will cause a shutdown

When total neutral is selected, the total neutral solenoid is not activated and as a result no pressure is supplied to the pressure intensifiers.

Pressure switch

The control valve also has a pressure switch installed between the total neutral shift spool and the pressure intensifiers supply. This switch will verify that a minimum pressure of 12 bar to the various pressure intensifiers is supplied only when the total neutral solenoid is activated. This information is an input of the APC200 box.

If a pressure is detected below 12 bar the controller will put the transmission in total neutral which causes a shut down.


TE17 TRANSMISSION - HYDRAULIC DIAGRAM
TOTAL NEUTRAL SELECTED


- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER RATIO 5:1
- (X) PRESSURE CHECK PORT
- (X) bar
- (X) TEMPERATURE CHECK PORT
- C

OPERATOR COMPARTMENT

PRESSURE GAUGE

TEMPERATURE GAUGE






OPERATOR COMPARTMENT

TE17 TRANSMISSION - HYDRAULIC DIAGRAM FORWARD 1st SELECTED

- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER RATIO 5:1
- (X) PRESSURE CHECK PORT
- (bar) bar
- (X) TEMPERATURE CHECK PORT
- (C)

PRESSURE GAUGE
TEMPERATURE GAUGE



PUMP 90 - 110 lpm @ 2200 RPM

AIR BREATHER
OIL SUMP
SCREEN

FWD CLUTCH

2nd CLUTCH

REV CLUTCH

1st CLUTCH

3rd CLUTCH

3 bar

71 C

32 bar

AA C

33

34

LUBRICATION RANGE CLUTCHES

Torque converter by-pass valve pressure difference 5 bar

Safety valve 9 bar

Pressure regulator valve 25-30 bar

Pressure reducer 10 bar

FILTER

BY-PASS VALVE Pressure difference 3.9 bar

VFS FWD

VFS 2ND

VFS REV

VFS 1/3

54

51

55

52 50

90 - 110 lpm @ 2200 RPM

45 bar

42 bar

46 bar

41 bar

43 bar

Total neutral

3RD / 1ST


HOSE

HOSE

Torque converter

COOLER



LUBRICATION RANGE CLUTCHES




OPERATOR COMPARTMENT

TE17 TRANSMISSION - HYDRAULIC DIAGRAM FORWARD 2nd SELECTED

- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER RATIO 5:1
- (X) PRESSURE CHECK PORT
- bar
- (X) TEMPERATURE CHECK PORT
- C










OPERATOR COMPARTMENT

TE17 TRANSMISSION - HYDRAULIC DIAGRAM FORWARD 3rd SELECTED

- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER RATIO 5:1
- (X) PRESSURE CHECK PORT
- (bar) bar
- (X) TEMPERATURE CHECK PORT
- (C) C

PRESSURE GAUGE
TEMPERATURE GAUGE






OPERATOR COMPARTMENT


PRESSURE GAUGE
TEMPERATURE GAUGE



TE17 TRANSMISSION - HYDRAULIC DIAGRAM REVERSE 1st SELECTED


- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER RATIO 5:1
- (X) PRESSURE CHECK PORT
bar
- (X) TEMPERATURE CHECK PORT
C







Check ports




Plug - Magnetic drain
M22 x 1.5 UNI

FRONT VIEW




Check ports



REAR VIEW




Check ports






Check ports






Check ports





Check ports



Port 32


Pressure
To cooler
Port 32

4 Mounting holes
M20 x 2.5 THD
30mm DEEP

BOTTOM VIEW



Check ports Control valve





Control valve installation instruction

Removing the valve

1. Make sure that the area around the valve is clean and that no dirt can fall into the valve during the disassembly procedure.
2. Unscrew the 7 bolts (marked green with a star on the drawing 1) until you feel that the tension is out of the bolt. **Do not remove them!**
3. Unscrew the 20 other bolts (marked blue on drawing 1) some turns. When all bolts are loose, you should be able to move the valve a bit
4. Remove 2 bolts (marked blue on drawing 1) and replace with aligning studs.
5. Remove the 15 bolts (marked pink on drawing 2)
6. Remove the remaining bolts (marked blue on drawing 1) and remove valve, note the sandwich plate between valve and housing




Control valve installation instruction

Installing the valve


1. Unscrew the 7 bolts (marked green with a star on drawing 1) until all tension is out of the bolt. **Do not remove them!**
2. Using aligning studs, install valve, sandwich plate and a new gaskets.
3. Hand tighten all bolts (marked blue and green on drawing 1) according to the sequence you find on the drawing 1.
4. Torque all bolts in the same sequence as on drawing 1 to a torque of 25Nm
5. Hand tighten the 15 bolts (marked pink on, drawing 2) and torque to 25Nm to the sequence as shown on drawing 2
- 6 Retorque all bolts (drawing 1 and 2) again to the sequences as shown
7. Recalibrate the transmission

Control valve installation instruction





Control valve installation instruction








Speed sensor installation




Speed sensor installation



On the sensor body there is a small plastic triangular position sign. Make sure the position sign on the sensor points as shown below in the direction of the movement of the gear teeth (Teeth rotation as shown).



Speed sensor installation



The magneto resistive sensor generates a square wave current with a fixed amplitude changing between 7 mA and 14 mA. The sensor has an integrated AMP superseal 2 pin connector. The two pins are numbered 1 and 2.

Following table shows the relation between wire colour, pin number and connection.

COLOUR	PIN NUMBER	FUNCTION	CONNECTION
BROWN	1	Current input	Hot wire
BLUE	2	Current output	Ground wire

Note

THE SENSOR WIRES HAVE A POLARITY.



BE SURE TO CORRECTLY OBSERVE SENSOR POLARITIES, AS WRONG CONNECTIONS WILL DEACTIVATE THE SENSOR !


Speed sensor installation

THIS MANUAL IS A PROPERTY OF DANA SPA. IT IS LOANED TO YOU BY DANA SPA. IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM. IT IS THE POLICY OF DANA SPA TO PROMOTE THE SAFETY AND HEALTH OF ALL OPERATORS OF ALL DANA EQUIPMENT. THE USER OF THIS MANUAL SHALL BE RESPONSIBLE FOR THE SAFETY OF ALL OPERATIONS.

1 INSTALL SENSOR WITH POSITION SIGN POINTING IN THE DIRECTION OF GEAR TEETH MOVEMENT OR 180° ROTATED


2 TORQUE SCREW : 9-11 lbf.ft (12-15 Nm)

3 INSTALL CLIP UNDER ANGLE X (SEE TABLE)



DETAIL SCALE 4:1

GEAR ROTATION



TRANSMISSION MODEL	ASSY PARTNR	CONNECTOR	TYPE	X POSITION
TE10	4209752	AMP 2 PINS	DRUM SPEED	0 DEGREES
	4209784	AMP 3 PINS	TURBINE SPEED OUTPUT SPEED ENGINE SPEED/ TEMPERATURE	0 DEGREES
TE13/17	4209831	DEUTZ 2 PINS	DRUM SPEED	-45 DEGREES
	4209832	DEUTZ 2 PINS	OUTPUT SPEED	-45 DEGREES
	4209833	DEUTZ 3 PINS	TURBINE SPEED ENGINE SPEED/ TEMPERATURE	-135 DEGREES
TE27/32	4209784	AMP 3 PINS	ENGINE SPEED/ TEMPERATURE	0 DEGREES
	4209752	AMP 2 PINS	DRUM SPEED	0 DEGREES
	4209750	AMP 2 PINS	OUTPUT SPEED	0 DEGREES
	4209751	AMP 2 PINS	TURBINE SPEED	-90 DEGREES

REVISION	DATE	BY	APPROVAL	REASON

ASSY-SPEED SENSOR
 INSTALLATION INSTRUCTIONS

43 BAF 0001. 01.



Spicer Off-Highway Products Division



TE32 transmission




Overview





TE32 :

- short drop
- 4 speed Fwd/Rev



Transmission Layout



- 1.  The converter, pump drive section and pressure regulating valve.
- 2.  The input shaft and directional clutches.
- 3.  The range clutches.
- 4.  The output section.



Model designation

1X.X T E 32 4 XX - XX

- Converter
- Model Wheel Group
- Mounting type
- Engine mount =T
- Remote mount =RT
- Mid mount =MT
- of gears
- Electronically controlled model
(x 100Nm)

specific "dash number"

specific ratio

even n° : long drop

odd n° : short drop

transmission input rating

numbers



Technical specifications

Ratio TE32418

TE32418	F1	F2	F3	F4	R1	R2	R3	R4
RATIO	5.065	2.422	1.379	0.784	5.065	2.422	1.379	0.784
SPREAD		2.091	1.757	1.760		2.091	1.757	1.760
TOT SPD				6.464				6.464
F/R ratio					1.00			



Technical specifications

Output flange rotation – (transmission forward clutch engaged)

<u>Model</u>	<u>Output</u>
Short Drop	Opposite
Long Drop	Same

Drop :


- Long Drop 624.6mm
- Short Drop 317.8mm



Technical specifications

Speed pick-up :

- Engine speed combined with temperature located on pump drive gear
- Turbine speed located on input gear
- Drum speed located on forward drum
- Output speed located on output shaft gear





Technical specifications

Converter/Transmission Oil System

Capacity (Approximate: measured at 600 RPM input speed and oil temp between 60 and 70°C, neutral)

Short drop 60L Long drop 75L Lines and cooler not included

Oil Type **ONLY** ATF Dexron III approved
viscosity at 40°C: 33 → 38 cSt
viscosity at 100°C: 7 → 8 cSt
flash point: min 160°C
pour point: max -42°C

Oil change 1000 hours

Filtration 2 x Spin On
change every 1000 hours
first change: 100 hrs or after rebuild



Temperature specifications

Normal operating temperature 70 - 120°C at temperature check port converter out

Maximum allowed transmission temperature 120° C

Pressure specifications

Transmission regulator pressure :

- 600 RPM 22.5-24.5 bar
- 2200 RPM 23.5-25.5 bar



Clutch pressures

At 1800 RPM 20.5 - 24.5 bar

Filter bypass

valve set at 4.1 to 4.5
bar

Lube pressure

0.9 – 1.4 bar at 100 l/min. lube flow.(+/-1000RPM)

Internal leakage @ 1800 RPM

Fwd/Rev max 4 l/min

1st max 9.2 l/min

2nd/3rd/4th max 4 l/min



Safety valve

cracking pressure 8.8-9.6 bar

Converter out pressure (to cooler)

5 bar min. at 2000 RPM and max. 8.5
bar at no load governed speed.

Pump flow

System pump flow : 108-128 l/min at 2200
RPM.

Lube pump flow : 80-95 l/min at 2200 RPM.

Electrical specifications

Variable force solenoids(VFS)

VFS 2nd/4th - VFS 1st/3rd - VFS Fwd -VFS Rev


Coil resistance 4.35 ± 0.35 OHMS. at 25° C

On/Off Solenoids

Total neutral , 1st/3rd & 2nd/4th range solenoids

Coil resistance 12V - 28 ± 2 . OHMS at 20° C

Coil resistance 24V - 87 ± 2 . OHMS at 20° C





Speed sensors

Type Magneto resistive sensor.
Sensing distance up to 1.8 mm
Sensor signal generates a square current with a fixed amplitude changing between 7 and 14 mA.



Drum speed sensor



Turbine and output (x2) speed sensor



Combined engine speed sensor and temperature



Hydraulic cooler line specifications

HYDRAULIC COOLER LINES SPECIFICATIONS.


Minimum 32 mm internal diameter for lines and fittings.

Suitable for operation from ambient to 120° C continuous operating temperature.

Must withstand 30 bar continuous pressure and 45 bar intermittent surges.


Conform SAE J1019 and SAE J517, 100RI.

EXTERNAL PLUMBING



Additional signals


- ◆ Speed sensors
 - Engine speed combined with oil temperature pick up located at pump gear
 - Turbine speed located on input gear
 - Drum speed located on forward drum
 - Output speed located on output gear
- ◆ Pressure feedback sensor
- ◆ Oil temperature
- ◆ Converter out temperature switch





Wiring schematics

TE 27/32 SOLENOID LOCATIONS





Wiring schematics


Pin	Wire color	Function
1-2	blue	VFS 4th/2nd
3-4	green	VFS FWD
5-6	yellow	VFS 3rd/1st
7-8	red	VFS REV
9-10	black	Total neutral
11	white	Presssure switch
12	yellow	Solenoid 4th/2nd
13	orange	Solenoid 3rd/1st
14	white	common ground sol 4/2 and 3/1
15	white	ground pressure switch
16		not used



Solenoids activated

<u>Transmission gear</u>	<u>Activated on /off solenoids</u>	<u>Activated VFS's</u>	<u>Activated Clutches</u>
Forward 4	Total neutral	Reverse, 1/3	Forward, 4 th
Forward 3	Total neutral	Reverse, 2/4	Forward, 3 rd
Forward 2	Total neutral, 2/4 selector	Reverse, 1/3	Forward, 2 nd
Forward 1	Total neutral, 1/3, 2/4 selector	Reverse, 2/4	Forward, 1 st
Neutral 4	Total neutral	Forward, Reverse, 1/3	4 th
Neutral 3	Total neutral	Forward, Reverse, 2/4	3 rd
Neutral 2	Total neutral, 2/4 selector	Forward, Reverse, 1/3	2 nd
Neutral 1	Total neutral, 1/3, 2/4 selector	Forward, Reverse, 2/4	1 st
Reverse 4	Total neutral	Forward, 1/3	Reverse, 4 th
Reverse 3	Total neutral	Forward, 2/4	Reverse, 3 rd
Reverse 2	Total neutral, 2/4 selector	Forward, 1/3	Reverse, 2 nd
Reverse 1	Total neutral, 1/3, 2/4 selector	Forward, 2/4	Reverse, 1 st

Electronic controlled modulation (E.C.M.)



Operation of transmission

The transmission is controlled by an APC200 box. This unit has a microprocessor that receives certain inputs (gear selector position, speed sensors,...), which are processed and will give output signals to the control valve.

Operation of the valve

Regulated pressure (22.5-25.5 bar) is directed to the total neutral shift spool and the pressure reducer that will decrease the pressure to 10 bar.

This reduced pressure will be used to supply the variable force solenoids(VFS), total neutral solenoid , 3rd/1st solenoid and 4th/2nd solenoid.

The VFS will give an output pressure curve from 0 to 6 bar proportional to a current from 1000 mA to 0 mA. The pressure intensifiers with a ratio of 3.5:1 will multiply this pressure curve so that a curve from 0 to 20 bar is available for each directional and range clutch. Between each VFS a pressure intensifier is placed and an accumulator to dampen any hydraulic vibration.

Directional selection

When a direction (forward or reverse) is selected , total neutral solenoid is activated and the required directional VFS will provide a pressure rise from 0 to 6 bar. The directional clutch is then fed with modulated pressure supplied through the pressure intensifier.

Operation of transmission

Range selection

When 1 st clutch is selected , the 3rd/1st and 4th/2nd solenoids are activated. The 1st/3rd VFS will provide a pressure curve from 0 to 6 bar. The pressure intensifier will multiply this pressure and will feed 1st clutch via the activated 3rd/1st spool.

When 2nd clutch is selected, The 3th/1st VFS will decrease pressure from 6 to 0 bar, thus releasing the 1 st clutch in a controlled fashion. At the same time the 4th/2nd VFS will provide a pressure curve from 0 to 6 bar . This pressure is fed to 2 nd clutch via the pressure intensifier, which will provide clutch overlap.

When the shift is finalised the 3rd/1st solenoid is deactivated.

When 3rd clutch is selected the 3rd/1st solenoid is not activated. The 1st/3rd VFS will provide a pressure curve from 0 to 6 bar and will feed 3rd clutch via a pressure intensifier and the deactivated 3rd/1st spool. At the same time the 4th/2nd VFS will decrease pressure from 6 to 0 bar providing the clutch overlap.

When the shift is finalised the 4th/2nd solenoid is deactivated.

When 4th clutch is selected , the 4th/2nd VFS will provide a pressure curve from 0 to 6 bar and will feed 4th clutch via a pressure intensifier and the deactivated 4th/2nd spool. At the same time the 3rd/1st VFS will decrease pressure from 6 to 0 bar providing the clutch overlap



Operation of transmission

Neutral selection

When neutral is selected (1st, 2nd, 3rd or 4th) , the total neutral solenoid is activated and the VFS's for forward and reverse are fed by a 1000mA current, which will result in a 0 bar output, thus providing 0 bar pressure to the forward and reverse clutch. The range clutches 1, 2,3 or 4 remain activated by their respective VFS.

Total neutral selection

Total neutral is only selected by the APC200 in case a severe error is detected which will cause a shutdown

When total neutral is selected, the total neutral solenoid is not activated and as a result no pressure is supplied to the pressure intensifiers.

Operation of transmission


Pressure switch


The control valve also has a pressure switch installed between the total neutral shift spool and the pressure intensifiers supply. This switch has 2 functions :


1. It will verify that a minimum pressure of 12 bar to the various pressure intensifiers is supplied only when the total neutral solenoid is activated. This information is an input of the APC200 box and if a pressure is detected below 12 bar the controller will put the transmission in total neutral which causes a shut down.
2. It will verify if only 1 direction clutch and 1 range clutch is activated when the shift is finalised. If detection is made that 2 direction clutches or 2 range clutches are hydraulically activated it will provide an input signal to the APC200 which will put the transmission in total neutral which causes a shutdown.


TE32 TRANSMISSION - HYDRAULIC DIAGRAM
TOTAL NEUTRAL SELECTED

- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER 0-6 TO 0-20 bar











Forward 1st

TE27/TE32 TRANSMISSION - HYDRAULIC DIAGRAM
FORWARD 2nd SELECTED

- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER 0-6 TO 0-20 bar




■ Lubrication
■ Low pressure
■ High pressure
■ Drain




Forward 2nd

TE27/TE32 TRANSMISSION - HYDRAULIC DIAGRAM
FORWARD 3rd SELECTED

- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER 0-6 TO 0-20 bar







Forward 3rd

TE27/TE32 TRANSMISSION - HYDRAULIC DIAGRAM
FORWARD 4th SELECTED

- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER 0-6 TO 0-20 bar




	Lubrication
	Low pressure
	High pressure
	Drain




Forward 4th

TE27/TE32 TRANSMISSION - HYDRAULIC DIAGRAM
REVERSE 1st Selected

- (A) ELECTRONIC CONTROLLED MODULATION VALVE 6 TO 0 bar
- (B) PRESSURE INTENSIFIER 0-6 TO 0-20 bar






Reverse 1st

Connections - top view

To remote filter from pump 2




Oil fill
3/4 npft

To remote filter from pump 1



Checkports - left view


Pressure check 1st clutch port 41




Oil level check port

1/4 NPT

Checkports - right view




Checkports - front view






Checkports - rear view




Speed sensor location

Engine speed & transmission temperature sensor





Checkports control valve



Checkport	4/4 SPEED (TE32)
31b	Regulator pressure (before total neutral)
49/51	VFS 4th/2nd
50/52	VFS 3 rd /1 st
54	VFS FWD
55	VFS REV
56	System pressure (after Total Neutral)
57	Solenoid (pilot)pressure
58	Press check range clutches
59	Press check direction clutches
66/61	Pressure intensifier 4th/2nd
60/62	Pressure intensifier 1 st /3 rd
64	Pressure intensifier FWD
65	Pressure intensifier REV




Control valve replacement

Removing the valve

1. Make sure that the area around the valve is clean and that no dirt can fall into the valve during the disassembly procedure.
2. Unscrew the 4 hex bolts (marked pink on drawing) until you feel that the tension is out of the bolt.
Do not remove them!
3. Unscrew the 15 other bolts (marked blue) some turns. When all bolts are loose, you should be able to move the valve a bit.
4. Remove 2 bolts (marked blue) and replace with aligning studs;
5. Remove the remaining bolts (marked blue) and remove valve

Installing the valve



1. Unscrew the 4 hexbolts (marked pink on drawing) until all tension is out of the bolt.
Do not remove them!
2. Using aligning studs, install valve and a new gasket.
3. Hand tighten all bolts(21) according to the sequence you find on the drawing.
4. Torque all bolts 2X in the same sequence as on the drawing to 25Nm
5. Recalibrate the transmission




Speed sensor installation

5.4 SPEED SENSOR INSTALLATION

On the sensor body there is a small plastic triangular position sign. Make sure the position sign on the sensor points as shown below in the direction of the movement of the gear teeth (Teeth rotation as shown).



Sensor installed




Hole plugged

Sensor position on transmission


Speed sensor installation

5.4 SPEED SENSOR INSTALLATION (CONTINUED)



The magneto resistive sensor generates a square wave current with a fixed amplitude changing between 7 mA and 14 mA. The sensor has an integrated AMP superseal 2 pin connector. The two pins are numbered 1 and 2. Following table shows the relation between wire colour, pin number and connection.

Colour	Pin Number	Function	Connection
BROWN	1	Current Input	Hot wire
BLUE	2	Current Output	Ground Wire



The magneto resistive sensor generates a square wave current with a fixed amplitude changing between 7 mA and 14 mA. The sensor has an integrated AMP superseal 3 pin connector. The three pins are numbered 1, 2 and 3. Following table shows the relation between wire colour, pin number and connection.

Colour	Pin Number	Function	Connection
RED	1	Current Input	Hot Wire
BLUE	2	Current Output	Ground Wire
GREEN	3	Temp. Input	Hot Wire

NOTE:
 THE SENSOR WIRES HAVE A POLARITY.
 BE SURE TO CORRECTLY OBSERVE SENSOR POLARITIES, AS WRONG CONNECTIONS WILL DEACTIVATE THE SENSOR.



Spicer Off-Highway Products Division

APC200 CONTROLLER



Overview

- ◆ Link with the transmission
- ◆ APC200
- ◆ APC200 display modes
- ◆ APC200 diagnostics
- ◆ System calibration

Transmission Input signals

- ◆ Speed sensors
 - Engine speed
 - Turbine speed
 - Drum speed
 - Output speed
- ◆ Pressure feedback switch
- ◆ Sump temperature sensor
- ◆ Converter out temperature switch



Control valve

- ◆ Proportional solenoids (VFS = “Variable Force Solenoid”)
 - VFS0 for forward
 - VFS1 for 2nd/4th (if used)
 - VFS2 for reverse
 - VFS3 for 1st / 3rd
- ◆ Pressure reducer
- ◆ Pressure intensifiers for each VFS (“boosters”)
- ◆ Selector solenoid 1st/3rd
- ◆ Selector solenoid 2nd/4th(if used)
- ◆ Total neutral solenoid




APC 200

- ◆ Device for shifting Spicer Off Highway Products ECM powershift transmissions (TE transmissions)
- ◆ ECM -> **E**lectronic **C**ontrolled **M**odulation
 - a transmission control technology, available on a range of transmission models
- ◆ ECI -> **E**lectronic **C**ontrolled **I**nching
 - to run at very low controlled speed at virtually any engine speed
- ◆ Overlap control
- ◆ Self diagnostics
- ◆ Throttle by Wire – engine control
- ◆ CAN Network Integration



Block diagram APC 200



APC200 Hardware Block Diagram

DISPLAY 8.8.8.8 (M) (S)

Communication RS232 CAN

Block diagram APC 200 : inputs


- ◆ 10 digital inputs
- ◆ 6 (7) analogue inputs
 - Ani0 Pressure feedback switch (resistance)
 - Ani1 Sump temperature (resistance)
 - Ani2 Converter out temperature switch (voltage)
 - Ani3 Aux f.ex. brake pedal (voltage)
 - (Ani4 Aux1 of anal. outputs (-pin) (reference voltage 5V))
 - Ani5 Aux2 of anal. outputs (-pin) f.ex. servo feedback (voltage)
 - Ani6 Aux3 of anal. outputs (-pin) f.ex. throttle pedal (voltage)
 - ⇒ input 0 to 2 have a fixed use
 - ⇒ input 3, 5 and 6 can be linked to external devices
- ◆ 4 speed inputs

Block diagram APC 200 : outputs (1/3)

- ◆ 4 digital outputs
 - Do0 RSP Drive Solenoid +
 - Do1
 - 2nd/4th selector (VFS1 is used for 2nd & 4th) on 4-speed
 - can be used for warning lamp on 3-speed transm. (Kalmar)
 - Do2 1st/3rd selector (VFS3 is used for 1st & 3rd)
 - Do3 RSP Drive Solenoid -

Block diagram APC 200 : outputs (2/3)

- ◆ Do0 and Do3 : RSP Drive Solenoid = “Total neutral” solenoid
- ◆ RSP = Redundant ShutDown Path
- ◆ ⇒ need of a fully reliable device to cut off pressure of all clutches in case of important failures (shutdown)
- ◆ Scheme :




Block diagram APC 200 : outputs (3/3)

- ◆ 7 analogue outputs
 - Closed loop current regulation for the VFS's :
 - VFS0 (fwd)
 - VFS1 (2nd/4th)
 - VFS2 (rev)
 - VFS3 (1st/3rd)
 - Aux1 to Aux3 : open loop current regulation
 - VFS4+ (servomotor engine control A)
 - VFS5+ (servomotor engine control B)
 - VFS6+ (analogue brake valve)
 - Remark servomotor : hardware version with H-bridge requested

Block diagram APC 200 : example


WIRE	PIN	FUNC	TYPE	DESCRIPTION	3/3 & 4/4 SPEED
A01	A1	A1	PPWR	Pwr	Permanent Battery Plus
A02	A2	B1	VFS0+	Pwm	Fwd VFS Hi Side Out
A03	A3	C1	VFS0-	Sns	Fwd VFS Lo Side In
A04	A4	D1	VFS1+	Pwm	2nd/4 th VFS Hi Side Out
A05	A5	E1	VFS1-	Sns	2nd/4 th VFS Lo Side In
A06	A6	F1	VFS2+	Pwm	Rev VFS Hi Side Out
A07	A7	G1	VFS2-	Sns	Rev VFS Lo Side In
A08	A8	H1	VFS3+	Pwm	1th/3th VFS Hi Side Out
A09	A9	J1	VFS3-	Sns	1th/3th VFS Lo Side In
A10	A10	K1	DO0	Stp	RSP Drive Solenoid +
A11	A11	A2	ANI0	Ptg	Pressure feedback
A12	A12	B2	DIGIN0	Ptp	Shiftlever 1-2
A13	A13	C2	DIGIN1	Ptp	Shiftlever 2-3
A14	A14	D2	DIGIN2	Ptp	Shiftlever 3-4
A15	A15	E2	DO1	Stp	2/4 VFS selector or alarm output
A16	A16	F2	DO2	Stp	1/3 VFS selector
A17	A17	G2	DIGIN3	Ptp	Shiftlever NEU
A18	A18	H2	DIGIN4	Ptp	Shiftlever FWD
A19	A19	J2	DIGIN5	Ptp	Shiftlever REV
A20	A20	K2	DO3	Stg	RSP Drive Solenoid -
A21	A21	A3	GND	Gnd	Supply ground
A22	A22	B3	SS0	Sns	Drum speed sensor+
A23	A23	C3	SS0	Gnd	Drum speed sensor -
A24	A24	D3	SS1	Sns	Output speed sensor+
A25	A25	E3	SS1	Gnd	Output speed sensor -
A26	A26	F3	SS2	Sns	Engine speed sensor+
A27	A27	G3	SS2	Gnd	Engine speed sensor -
A28	A28	H3	ANI1	Ptg	TransmTemperature
A29	A29	J3	ANI2	Ptg	Cooler input temperature
B00	A30	K3	GND	Gnd	Signal ground

WIRE	PIN	FUNC	TYPE	DESCRIPTION	3/3 & 4/4 SPEED
B01	B1	L1	VFS4+	HbrgA	Engine control motor A
B02	B2	M1	ANI4	Sns	5V Reference voltage out
B03	B3	N1	VFS5+	HbrgB	Engine servo motor B
B04	B4	P1	ANI5	Sns	Engine servo pos. input 0-5V
B05	B5	R1	VFS6+	Pwm	Analog brake valve
B06	B6	S1	ANI6	Sns	Accelerator pedal analog input 0-5V
B07	B7	L2	CANL	Comm	CAN Lo
B08	B8	M2	CANH	Comm	CAN Hi
B09	B9	N2	RXD	Comm	RS232 RXD
B10	B10	P2	TXD	Comm	RS232 TXD / SPEEDO OUT
B11	B11	R2	SS3	Sns	Turbine speed sensor+
B12	B12	S2	SPWR	Pwr	Switched Battery Plus
B13	B13	L3	DIGIN6	Ptp	Inching Enable switch
B14	B14	M3	DIGIN7	Ptp	manual / automatic selection
B15	B15	N3	DIGIN8	Ptp	Parking Brake OFF/ON
B16	B16	P3	DIGIN9	Ptp	
B17	B17	R3	ANI3	Ptg	Brake pedal analog input 0-5V
B18	B18	S3	SGND	Gnd	Signal Ground



PSU = Power Supply Unit

- ◆ Version : 12V or 24V
- ◆ Two power lines
 - PPWR : permanent power
 - Connected directly to the battery
 - SPWR : switched power
 - Connected via key contact to the battery




Bootstrap and reset circuit

- ◆ Bootstrap:
 - Special mode, controller wants to receive serial data, to program the firmware into the program memory
 - While in bootstrap all output functions are hold off
 - Start : during power up both buttons pressed
- ◆ Reset circuit : watchdog & supply supervisor will reset the CPU if either the feedback from the watchdog is outside 10% of timing tolerance or if the CPU has “forgotten” to re-trigger the watchdog trigger

Functions

- ◆ Manual / automatic shifting
- ◆ Electronic modulation
- ◆ Overlap control
- ◆ Electronic inching
- ◆ Start 1st / 2nd
- ◆ Limit vehicle speed
- ◆ Reduce vehicle speed (by use of an input)
- ◆ Limit engine speed
- ◆ Direction change protection (speed and engine RPM)
- ◆ Declutch (in normal mode : neutral / in inching : offset pressure)
- ◆ Engine control
- ◆ Seat orientation
- ◆ Hydro lever function in neutral

Functions on wiring diagram



Communication

- ◆ CAN 2.0 B
 - Communicate with different controllers and PC

- ◆ RS 232
 - To flash a new firmware (main program)
 - To download the parameter settings (APT-file)
 - To edit specific parameters (GDE-file)

Parameter setting

1 approved drive-line = 1 APT-file

Approved drive-line =


Specific type of vehicle + specific engine + specific
transmission (+ axle + tires)

Display

- 4 red 7-segment LED digits
- 3 status LED lamps
 - D -> yellow, test modes
 - E -> yellow, faults
 - F -> red, APC 200 in reset conditions (f.ex. bootstrap)
- 2 push buttons
 - M -> which information group
 - S -> item within group




Display modes




Display modes

- ◆ “GPOS” display
 - Reflects the actually engaged transmission direction and range




Display modes

- ◆ “VSPD” display
 - Shows the vehicle speed in km/h or MPH, with a resolution of 0.1 km/h or 0.1 MPH




Display modes

- ◆ “dist” display
 - Shows the distance travelled in km or miles, with a resolution of 0.1 km or 0.1 miles




Note : the distance can be reset by pushing the “s” button during 3 seconds when being in this display mode.

Display modes




Display modes

- ◆ “CPOS” display
 - Reflects the actually shiftable position




Display modes

- ◆ “Espd” display
 - Shows the measured engine speed in RPM




Display modes

- ◆ “Tspd” display
 - Shows the measured turbine speed in RPM




Display modes

- ◆ “Ospd” display
 - Shows the measured output speed in RPM




Display modes

- ◆ “Srat” display
 - Reflects the current speed ration ($Tspd / Espd$), which is an important factor in automatic shifting




Display modes

- ◆ “TQ I” display
 - Reflects the measured torque (turbine torque) at the transmission input side in Nm




Display modes

- ◆ “Ttmp” display
 - Shows the transmission sump temperature in °C




Display modes

- ◆ “Ctmp” display
 - Shows the Converter out temperature in °C





Note : due that the converter out temperature is measured by a temperature switch : 50 on the display means below 120° C
150 on the display means above 120° C

Display modes




Display modes


- ◆ “Err” display
 - Shows all existing error codes (none blinking error code) and error codes detected in the past (blinking error code).



(none blinking)



(blinking)



(end of faults)

Note : when an error is active,
the error led will be blinking

Error codes list

Microsoft Excel - Failure codes.xls [Read-Only]

File Edit View Insert Format Tools Data Window Help

Times New Roman 10 B I U % , +.0 +.00


G96 = Check the wiring between the controller and the pressure

SPICER OFF-HIGHWAY : APC200 - FAULT DESCRIPTION							
						Revision : 1.00 - 28 february 200	
1	DANA						
2							
3							
4							
5							
6	Fault code	Type	Explanation	Controller's action	Driver action	Fault cause	Troubleshooting
7							
8	00.50	S	There is a problem related to the internal RAM (in CPU).	Controller reverts to a "shut down" mode and will force neutral 0	- Stop machine - Contact maintenance for troubleshooting	Hardware related fault - related to in the internal RAM.	Contact Spicer Off-Highway and inform the fault code and the tire that it was active.
10	00.51	S	There is a problem related to the system RAM (in CPU).	Controller reverts to a "shut down" mode and will force neutral 0	- Stop machine - Contact maintenance for troubleshooting	Hardware related fault - related to in the system RAM.	Contact Spicer Off-Highway and inform the fault code and the tire that it was active.
12	00.52	S	There is a problem related to the external RAM.	Controller reverts to a "shut down" mode and will force neutral 0	- Stop machine - Contact maintenance for troubleshooting	Hardware related fault - related to in the external RAM.	Contact Spicer Off-Highway and inform the fault code and the tire that it was active.
14	00.53	S	There is a problem related to the Flash program memory.	Controller reverts to a "shut down" mode and will force neutral 0	- Stop machine - Contact maintenance for troubleshooting	Hardware related fault - related to in the flash program memory.	Contact Spicer Off-Highway and inform the fault code and the tire that it was active.
16	20.60	S	Pressure feed-back line is indicating there is no system pressure present, although pressure should be there	Controller reverts to a "shut down" mode and will force neutral 0	- Stop machine - Contact maintenance for troubleshooting	The analog input AMI0 is in the 500 - 1500 ohm range, while it should be in the 1500 - 4000 ohm range	Check the wiring between the controller and the pressure feedback sensor. Check the pressure feedback sensor (engine running / stopped).
18	20.61	S	Pressure feed-back line is indicating there is system pressure present, although pressure should NOT be there	Controller reverts to a "shut down" mode and will force neutral 0	- Stop machine - Contact maintenance for troubleshooting	The analog input AMI0 is in the 1500 - 4000 ohm range, while it should be in the 500 - 1500 ohm range	Check the wiring between the controller and the pressure feedback sensor. Check the pressure feedback sensor (engine running / stopped).
20	30.04	S	Power supply (24V) out of range -> below minimum	Controller will save all loaged information to flash will powerdown, and force all outputs off	- Stop machine - Contact maintenance for troubleshooting	Power supply to the controller is below 8	Check power supply cables to the controller. Check alternator, check the connection cables between the batter and the alternator, check the battery.
22	30.05	B	Power supply (24V) out of range -> above maximum	The controller will have reduced proportional control accuracy due to reduced PWM duty cycle	- Contact maintenance for troubleshooting	Power supply to the controller is above 3	Check power supply, check if a jump start setup is still connecte
24	31.00	A	Voltage supply for the sensors : Vsense is out of range -> below minimum	The controller will have reduced sensor signals	- Contact maintenance for troubleshooting	Voltage supply for the sensors : Vsense is below 7,2 V	Check power supply. Check the controller.
26	31.01	A	Voltage supply for the sensors : Vsense is out of range -> above maximum	The controller will have reduced sensor signals	- Contact maintenance for troubleshooting	Voltage supply for the sensors : Vsense is above 8,8 V	Check power supply. Check the controller.
28	40.06	A	Invalid shift lever direction detected	The controller will force neutral.	- Contact maintenance for troubleshooting	The controller receives from the shiftlever a request to enqage forward and reverse	Check the wiring between the controller and the shiftlever conce the forward and the reverse signal.

Fault overview

Draw AutoShapes

Diagnostics




Power up
+ (S)




Display test

Note : for the firmware version, the display is using a scrolling text moving to the left (continuously).

Diagnostics



Digital input test



Digital input reference




Digital input 3 on wire 17



input not active

Note : input 10 till 13 are the 4 analog inputs, which could be used as digital inputs

Diagnostics



Analog input test


No . meaning the value is in Ω

1st value (k Ω or V) of the 1st 4 analog inputs


A . meaning the value is in Volts

Analog input 3 on wire 47 (47 – 30 pins on connector A = B17)


Diagnostics



Diagnostics



Diagnostics





Calibration APC200-Transmission

- ◆ Menu structure overview
- ◆ Transmission calibration (clutch filling)
- ◆ Heat mode
- ◆ Calibration of the analogue inputs :
 - Throttle pedal
 - Brake pedal
 - Hydro lever
 - Servo motor



Transmission calibration (clutch filling) Introduction

- ◆ What?
- ◆ Is determining volume of oil that is needed to fill up the clutch, until clutch plates start to transfer torque.
- ◆ This start of torque transfer is the point when the programmed modulation curve starts to act.
- ◆ Since each transmission, clutch, valve and VFS has its own tolerances, this fill capacity needs to be determined on newly assembled units and every time any of these components is changed.



Transmission calibration (clutch filling) Introduction

- ◆ How ?
- ◆ Direction (FWD/REV)clutches are calibrated by fully activating 2nd range clutch, and then by gradually increasing the pressure signal from the directionalVFS until a drop in turbine RPM is noted. This drop in turbine RPM is the touch detection i.e. the point at which the clutch starts to transfer torque. This VFS signal is stored in the memory of the APC200 and is used as the start point for the modulation which was predetermined during prototype testing.
- ◆ Range clutches (1st, 2nd, 3th and 4th) are calibrated by fully activating forward clutch and then by gradually increasing the pressure signal to the corresponding range VFS as above.



Transmission calibration (clutch filling) Introduction


- ◆ A transmission calibration has to be performed :
 - when the vehicle is built at the OEM
 - after 2000 hours driving in gear (forward or reverse)
 - when the valve is changed
 - when an overhaul of the transmission is done
 - when the transmission is repaired / replaced
 - when the APC200 is replaced
 - when firmware and APT-file are updated

- ◆ Goal :
 - guarantee the best shift quality during the complete life of the transmission



Transmission calibration (clutch filling) How ? (1/3)

- ◆ Enter the calibration menu by pressing the S-button on the APC200 display for 15 s during power up of the APC :




- ◆ Push the S-button to trigger the transmission calibration
- ◆ Before the calibration can be started, a number of conditions need to be fulfilled :
 - parking brake has to be activated
 - sump temperature has to be $> 60^{\circ}\text{C}$ (cfr. Heat mode)
 - engine speed has to be kept within 800 ± 200 rpm (note: if the APC has control over the engine, the speed will be adapted automatically)




Transmission calibration (clutch filling) How ? (2/3)

- ◆ If all these conditions are met, the APC will ask to shift to forward to start the calibration :



- ◆ The transmission calibration now starts. This is indicated on the APC200-display :




etc. ('c1' = clutch 1 i.e. fwd ; 'M1' = mode 1 of the calibration)



Transmission calibration (clutch filling) How ? (3/3)

- ◆ When all clutches have been calibrated, the APC200 displays :




- ◆ This means the calibration has been completed successfully. Normal duration : about 15 min.
- ◆ Now switch off the ignition key of the vehicle and let the APC power down.
- ◆ When restarting the vehicle, the calibration results will be activated automatically.
- ◆ Important : by selecting REVERSE, the calibration is stopped immediately (APC powers down).



Heat mode (1/3)

- ◆ Goal : warm up transmission in a fast way (stall)
- ◆ Specific to heat mode :
 - fwd/rev can be selected while the parking brake is on
 - disables inching and declutch
 - the highest gear is forced (3rd or 4th)
- ◆ How ? Push M-button when 'trAn' is on the display :




- ◆ Push the S-button to trigger the heat mode : actual sumpt°



Heat mode (2/3)

- ◆ Perform the following scheme to warm up the transmission :



- ◆ When the sumpt is above 60 °C, the indication on the APC display starts blinking.
- ◆ Now push the M-button until you come back to 'trAn'










Heat mode (3/3)

- ◆ Note : When the converter out temperature would exceed 120°C, the engine speed will be limited to half throttle (if APC has engine control) or the transmission will be forced to neutral (when APC has no engine control).

Other messages during calibration (1/5)


◆ 1. Calibration condition messages

	<p>The APC200 expects the shift lever to be in neutral, but finds it in another position (forward or reverse).</p>	<p>Put the shift lever back to neutral.</p>
	<p>The APC200 expects the parking brake to be on while it is off.</p>	<p>Put the parking brake to on.</p>
	<p>The APC200 has detected output speed.</p>	<p>Verify if the parking brake is on and working properly. If this is already the case, you will be obliged to keep to machine at standstill by using the footbrake. Once the machine has been stopped, the APC200 will ask the driver to shift to forward before continuing the calibration.</p>
	<p>Engine rpm is too low according to the limit that is necessary for calibration.</p>	<p>If the vehicle is equipped with throttle-by-wire, the engine rpm will be automatically adapted. In the other case, the driver has to change the throttle pedal position until the display looks as follows :</p> <div style="text-align: center;">  </div>
	<p>Engine rpm is too high according to the limit that is allowed for calibration.</p>	
	<p>After being too low or too high, the engine rpm is coming back into the correct boundaries for calibration.</p>	



Other messages during calibration (2/5)

- ◆ 1. Calibration condition messages (part 2)

	<p>When during the automatic transmission calibration the temperature becomes too low, the APC200 display indicates the actual transmission temperature.</p>	<p>Use the M-button on the APC200 to go back to the 'HEAT'-mode and the S-button to trigger this mode. Now, you have to warm up the transmission again until the temperature is above 60° C. Then go back to the automatic tuning mode by the M-button and trigger this one again to continue the calibration.</p>
-----------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



Other messages during calibration (3/5)

◆ 2. Calibration error messages

□ E1.25 : during calibration, early touch detect.

Possible causes :

- Too much clutch drag because of too thick oil, recalibrate at higher temperature 90 -100 °C)
- Sticking or burnt clutch which causes turbine to drop before pressure is applied,

□ E1.26 : during calibration, no touch detect.

Possible causes :

- VFS faulty (no out put pressure)
- Slipping clutch or too high internal leakage



Other messages during calibration (4/5)

- ◆ 2. Calibration error messages continued

- ◆ E1.10 : during calibration, shift inhibit.
Possible causes :
 - Caused by shutdown e.g; in combination with 20/60 error;
 - Resolve cause of shutdown before recalibration



Other messages during calibration (5/5)

- ◆ 2. Calibration error messages continued
 - E2.14 : calibration failed ,fill time out.
Possible causes :
 - Turbine speed does not decrease caused by too high internal leakage and or slipping clutch


 - E2.16 : calibration failed , turbine pull down too early.
Possible causes :
 - Faulty turbine speed sensor




Calibration of analogue inputs

Example : brake pedal (1/4)

- ◆ Enter the calibration menu by pressing the S-button on the APC200 display for 15 s during power up of the APC.
- ◆ When having 'trAn' on the display, push the M-button until you see



- ◆ Push the S-button to trigger the brake pedal calibration
- ◆ The APC now asks for the idle position of the brake pedal (no play in the pedal anymore) :




- ◆ Push the S-button to confirm the position.



Calibration of analogue inputs Example : brake pedal (2/4)

- ◆ Then, the APC asks for the mid position of the brake pedal (point where the brakes start to operate) :




- ◆ With hydraulic brakes : this point corresponds to the moment the brakes start 'sissing'
- ◆ With dry brakes : push the pedal a little bit, just enough to make the position led stop blinking (if blinking, there is not enough position difference / former position). When doing so, the midpoint is automatically clipped at 5%.
- ◆ Push again the S-button to confirm the position.




Calibration of analogue inputs Example : brake pedal (3/4)

- ◆ Finally, the APC asks for the full brake position :



- ◆ Apply full brake and press the S-button to confirm.
- ◆ If the calibration has been successful, the APC display will show




- ◆ Now switch off the contact key. The calibration values are automatically stored into the APC200.



Calibration of analogue inputs

Example : brake pedal (4/4)





TE transmission field experience

- ◆ TE13/17 field campaign
- ◆ Speed sensor changes
- ◆ Case studies



TE transmission field experience

- ◆ TE13/17 field campaign

Clutch end plate snapping jumps out of groove, causing slipping clutch.

Only clutches in combination with a spacer between endplate and snapping are affected

Fix is a one piece endplate

Population : all units built prior to April 2004



TE transmission field experience

- ◆ Speed sensor changes.

Cracked speedsensor housing causes potting material to swell which results in speed sensor touching the gear.

solved by changing potting material and new speed sensors moulds

Latest version is recognisable by a coloured ring around the housing

Installation : refer to drawing



TE transmission field experience

◆ Case studies

1. Vehicle stops error 00.50

action 1 : Change APC and calibrate

error E1.25 and E2.14 in 2nd

vehicle only drives in second

action 2 : changed valve and recalibrate

error 20.60 before calibration can start

action 3 : measure clutch pressure (0 bar), measure lube pressure (0bar), check pump (OK) found sandwich plate on valve not fitted during exchange, refitted sandwich plate and recalibrate

error E1.25 and E2.14

vehicle only drives in 2nd and blocks in 1st and 3rd

action 4 : replace transmission, faulty unit had a burnt 2nd clutch

Comments, A 20/60 error indicates a system pressure fault, 1st step should be to check system pressure



TE transmission field experience

◆ Case studies

2. Vehicle has a delay when downshifting, no error codes

action 1 : replace speed sensors and valve
no improvement

action 2 : test drive confirms that downshiftspeedpoints are lower than
on similar vehicle, recalibrate throttle switch

No improvement

action 3 : test drive shows that speed ratio and turbine speeds are
correct when down shift is made, indicating a changed converter
characteristic which causes loss of tractive effort ; measure stall speed
which shows only 1200 RPM i.o. 1800 RPM.

Replace transmission which shows a failed converter freewheel

Comments: the delay was not clearly understood. This case proofs that
basic converter/transmission troubleshooting is still valid (measure stall
speed),



TE transmission field experience

◆ Case studies

3. Tel call : machine sometimes shows 20.60 error code

action 1 : recalibrate transmission

Error codes : E1.26; E2.14

vehicle symptoms : slips in third, oil is contaminated

replace transmission which shows a 3 rd clutch failure

commnets, The 20/60 appeared only when 3rd clutch is selected, this indicates a high 3rd clutch leakage? The symptoms confirm this; behind the 20/60 error a 42.05 should have been found, but this was not checked.

A 20/60 only on TE32 can also indicate that two range or direction cluthes are engaged at the same time. Pressure checks should confirm this .



TE transmission field experience

◆ Case studies

4. Tel call : unit shocks when 4th is selected and goes back to 3rd , no error codes

action 1 check 4th clutch pressure : 5 bar

action remove transmission and send for repair

nothing found wrong, reinstalled unit and is OK... for 2 days when problem reappears

action 2 : check CPOS and GPOS on APC200

CPOS shows only FWD 3

action 3 : replace cab control

Problem solved

comments : The cab control had an intermittent fault causing 4th to engage and disengage; this causes the VFS 4/2 to rise and fall in pressure quickly which explains the 5 bar measured . The suspected 4 th clutch failure should have been confirmed by error codes.



TE transmission field experience

◆ Case studies

5. Tel call : failure code 20/61 with engine not running
pressure switch blocked in closed position.

Action 1 : replace pressure switch
problem solved

comment : 20/61 indicates system pressure when it should not be there.
Since engine is not running there can be no system pressure indicating
a jammed switch

If 20/61 occurs with engine running it is most probably caused by a
faulty engine speed sensor which generates 0 RPM



TE transmission field experience

◆ Case studies

6. Tel call : error code 42/04 (speed ratio (Turbine/Output) too low
action 1 replace turbine speed sensor

Problem solved

comment : too low speed ratio is a wrong speed measurement or a wrong ratio. Since a wrong ratio is least likely the turbine or output speed sensor are at fault

42/05 error (speed ratio too high) can be caused by the same speed sensors if this fault appears in all speeds/directions. If it only appears in one speed or one direction you have to assume a slipping clutch.



Spicer Off-Highway Products Division

Thanks