




Подключить к
Arduino 3.3 V




Подключить к
порту Arduino RX

Подключить к
порту Arduino RX



Подключить к порту
Arduino GND






СОЗДАНИЕ ПРИЛОЖЕНИЯ ПУЛЬТА ДИСТАНЦИОННОГО УПРАВЛЕНИЯ

РОБОТОМ НА ОС ANDROID

The screenshot displays the MIT App Inventor web interface. At the top, the MIT App Inventor logo is on the left, and navigation links for 'Projects', 'Connect', 'Build', and 'Help' are in the center. On the right, there are links for 'My Projects', 'Gallery', 'Guide', 'Report an Issue', 'English', and a user email 'kredopo@gmail.com'. Below the navigation bar, the application title 'Car' is shown, along with 'Screen1' and buttons for 'Add Screen ...' and 'Remove Screen'. The interface is divided into four main panels:

- Palette:** A list of user interface components such as Button, CheckBox, DatePicker, Image, Label, ListPicker, ListView, Notifier, PasswordTextBox, Slider, Spinner, Switch, TextBox, TimePicker, and WebViewer.
- Viewer:** A central window showing a mobile app preview. The app has a status bar at the top with signal, Wi-Fi, and battery icons, and the time 9:48. Below the status bar is a 'Connect' button. The main area features a central square with four green arrows pointing up, down, left, and right. At the bottom of the app is a grid of percentage buttons: 0%, 80%, 70%, 80%, 90%, and 100%. A 'Non-visible components' section is visible at the bottom of the viewer.
- Components:** A tree view showing the hierarchy of components on the screen: Screen1, ListPicker1, TableArrangement1, and ten Button components (Button1 through Button10). A Bluetooth component labeled 'КлиентBluetooth1' is also listed.
- Properties:** A panel for configuring the selected component, ListPicker1. It includes settings for BackgroundColor (Default), ElementsFromString, Enabled (checked), FontBold, FontItalic, FontSize (14.0), FontTypeface (default), Height (Automatic...), Width (Fill parent...), Image (None...), and ItemBackgroundColor (Default).

СВОЙСТВА КНОПОК ДВИЖЕНИЯ



СВОЙСТВА КНОПОК ВЫБОРА МОЩНОСТИ

