


USB Gateway Set-up Manual in Windows VISTA




A. Turn User Account Control Off

1. Start – Control Panel



A. Turn User Account Control Off

2. User Accounts



A. Turn User Account Control Off

3. Turn User Account Control on or off




A. Turn User Account Control Off

4. Disable 'Use User Account Control (UAC) to help protect your computer'




A. Turn User Account Control Off

5. Restart



B. USB Driver Set-up

1. Preparing Driver Files




B. USB Driver Set-up

2. Connect USB Gateway to PC




B. USB Driver Set-up

3. Found New Hardware




B. USB Driver Set-up

4. Browse for driver files



B. USB Driver Set-up

5. Search for driver files




B. USB Driver Set-up

6. Browse for driver folder



B. USB Driver Set-up

6. Browse for driver folder



B. USB Driver Set-up

7. Select 'Install this driver software anyway'



B. USB Driver Set-up

8. Driver Set-up Completed

