

Effect of polycarboxylate ether and citric acid on hydration of sulfoaluminate cement

Program M2
Internship at SPIN Center-PMMG

Performed by: Angsar SERIKKALI Supervised by: Alexandre GOVIN

INSPIRING INNOVATION SINCE 1816





Outline

- General Introduction
- Materials and methods
- Results and Discussion
- Conclusion





Introduction

What is happening in cement production nowadays? What kind problems cement industry face with?

Portland cement is relatively low embodied energy compared to other building materials [Bing et al. 2014]

Manufacturing of Portland cement consumes approximately 2-3% of global energy [Juenger et al. 2011]

Cement industry contributes 5% of manmade carbon dioxide emissions [Bing et al. 2014]









Introduction

Why calcium sulphoaluminate cement?

CSA have attracted the attention of scientists, as well as of industry [Zajac et al. 2016]

Portland cements are produced from the firing of a calcite at a temperature of about 1450 °C [Bullerjahn. 2018]

CSA cements are produced by burning of clinker at 1250°C [Winnefeld. 2012]

CSA cements are not widely used in Europe and U.S.; its used in China for about 30 years [Winnefeld. 2012]



Introduction

Hydration of CSA cement

The hydration of cement is in simple terms of dissolution/precipitation process [Scrivener et al. 2011]

1.
$$C_4A_3\overline{S}+18H \rightarrow C_4A\overline{S}H_{12}+2AH_3$$

2.
$$C_4A_3\overline{S}+98H \rightarrow C_6A\overline{S}_3H_{32}+CAH_{10}+2AH_3$$

3.
$$C_4A_3\overline{S}+C\overline{S}+38H \rightarrow C_6A\overline{S}_3H_{32}+2AH_3$$

$$\textbf{4.} \quad \textbf{C}_{4}\textbf{A}_{3}\overline{\textbf{S}} + \textbf{C}\overline{\textbf{S}} + \textbf{28H} \ \rightarrow \ \textbf{0.5C}_{6}\textbf{A}\overline{\textbf{S}}_{3}\textbf{H}_{32} + \textbf{0.5C}_{4}\textbf{A}\overline{\textbf{S}}\textbf{H}_{12} + \textbf{2AH}_{3}$$

The cement notation:

 $A=Al_2O_3$, C=CaO, $H=H_2O$, $S=SiO_2$, $\overline{S}=SO_3$

[Bullerjahn 2018]












Materials

Polycarboxylate ether



Name	Pure solide mw%	Р	N	n (Mp)	Mw
PCE 1	20%	45	5	12	48272
PCE 2	25%	114	5	15	138594
PCE 3	30%	17	2.5	113	118984



CSA cement



_	7
	\checkmark

	· ·						
	Ye'elimite (C4A3\$)	Belite (C2S)	Anhydrite (C\$)	Bredigite	Periclase (MgO)	Fluorite	Cacium Iron Oxide
		Larnite		(Ca14Mg2(SiO4)4)	reficiase (MgO)	(CaF2)	(CaFe3O5)
	49.44	8	21.9	11.25	4.84	3.13	1.43


Citric acid















Overview of the used techniques

Characterisation	Methods	Location	Analyzed by	
	pH, conductivity, stoppage test	EMSE (C3-01)	Angsar SERIKKALI	
	ICP	EMSE (D3-14)	Frederic GALLICE, Angsar SERIKKALI	
Hydration reactions and kinetics	IC	EMSE (D3-14)	Frederic GALLICE, Angsar SERIKKALI	
	тос	EMSE (C2-10)	Angsar SERIKKALI	
Saturation indexes	Thermodynamic modelling	EMSE (C3-08)	Angsar SERIKKALI	
Minaral a ammosition	XRD	EMSE (D0-16)	Olivie VALFORT, Angsar SERIKKALI	
Mineral composition	TGA	EMSE (C2-05)	Angsar SERIKKALI	





Conductivity



CDM210-MeterLab


- V=1L
- Double walled and water-jacketed reactor
- T=24.6 °C±0.2
- 270-350 r/min
- Experiment time is around 24 hours
- Water to cement ratio: 20

Calibration: m_{KOH} =2.2365 g and δ =2.097 mS/cm





Conductivity




Name of experiments	Water (L)	Cement (g)	Admixture	
CSA (Reference)	1	50	-	
CSA+PCE 1	1	50	0.1-0.3%* PCE 1	
CSA+PCE 2	1	50	0.1-0.3%* PCE 2	
CSA+PCE 3	1	50	0.1-0.3%* PCE 3	
CSA+CA	1	50	0.2%* CA	
CSA+CA	1	50	0.4% * CA	
*% is shown regarding to the mass of cement (50 g)				





Stoppage test







Solid part and liquid part methods

Solid part

X-ray powder diffraction (XRD)

- X-ray diffractometer (BRUKER D8-A25)
- X-ray tube (Cu radiation)
- X-ray detector (Lynxeye XE-T)
- 2θ from ~5° to 90° with rate of diffraction each 0.015°
- Software: DiffracEVA
- Preparation method is backloading
- m=1g; 40% mw ZnO

Thermogravimetric analysis (TGA)

- Instrument : SETARAM 92-16.18
- · Gas: He
- Heating: Temperature from 30°C to 900°C; with rate of heating 10°C/min
- m=100-105 mg
- Data is fitted in the program Fytik





Solid part and liquid part methods

Liquid part

Inducted coupled plasma (ICP)

- Instrument:
- V=8 ml with
 - x10 dilution by 0.1M HCl
 - x100 dilution by 0.001M HCl
- Storage T=4°C
- Results in ppm for : Al, Ca, Fe, K, Na, S and Si

Total organic carbon (TOC)


- Instrument:
- V=8 ml
- T=850°C
- Gas: O₂

Ionic chromatography (IC)

- Instrument:
- V=8-10 ml
 - x100 dilution by 0.1 HCl
 - x1000 dilution by 0.1 HCl
- T=850°C
- Gas: O₂







 Pure dissolution period for ye'elimite is 30 seconds






Conductivity & ICP

- ye'elimite dissolves rapidly
- etrringite continues to form slowly
- the highest dissolution/precipitation ratio
- formation of crystalline AH₃
- $1. \quad C_4 A_3 \overline{S} + 18 H \ \rightarrow \ C_4 A \overline{S} H_{12} + 2 A H_3$
- $\textbf{2.} \quad \textbf{C}_{4}\textbf{A}_{3}\overline{\textbf{S}}\textbf{+98H} \,\rightarrow\, \textbf{C}_{6}\textbf{A}\overline{\textbf{S}}_{3}\textbf{H}_{32}\textbf{+}\textbf{C}\textbf{A}\textbf{H}_{10}\textbf{+2}\textbf{A}\textbf{H}_{3}$
- 3. $C_4A_3\overline{S}+C\overline{S}+38H \rightarrow C_6A\overline{S}_3H_{32}+2AH_3$
- $\textbf{4.} \quad \textbf{C_4A_3}\overline{\textbf{S}} + \textbf{C}\overline{\textbf{S}} + \textbf{28H} \ \rightarrow \ \textbf{0.5C_6A}\overline{\textbf{S}_3} \textbf{H_{32}} + \textbf{0.5C_4A}\overline{\textbf{S}} \textbf{H_{12}} + \textbf{2AH_3}$

The cement notation:


 $A=Al_2O_3, \ C=CaO, \ H=H_2O, S=SiO_2, \overline{S}=SO_3 \quad \textbf{[Bullerjahn. 2018]}$








Conductivity of superplasticizers








Conductivity of reference, superplasticizers and citric acid











XRD results









XRD results

There is only qualitative analyses, not quantitative!













Thermodynamic modelling (SI) results







TGA results







Conclusion

Conductivity analyses

- Reference
- 0.1-0.3% PCE 1
- 0.1-0.3% PCE 2
- 0.1-0.3% PCE 3
- 0.2% and 0.4% CA

IC,ICP and TOC analyses

- Reference
- 0.2% PCE 1
- 0.2% PCE 2
- 0.2% PCE 3
- 0.2% and 0.4% CA

Thermodynamic modelling (SI)

- Reference
- 0.2% PCE 1
- 0.2% PCE 2
- 0.2% PCE 3
- 0.2% and 0.4% CA

TGA analyses

- Reference
- 0.2% PCE 1
- 0.2% PCE 2
- 0.2% PCE 3
- 0.2% and 0.4% CA

XRD analyses

- Reference
- 0.2% PCE 1
- 0.2% PCE 2
- 0.2% PCE 3
- 0.2% CA





Conclusion

1



2

Ye'elimite 💥

