

# Fast Frequency and Response Measurements using FFTs

**Alain Moriat,**  
Senior Architect  
Fri. 12:45p  
Pecan (9B)

# Accurately Detect a Tone

---

- What is the exact frequency and amplitude of a tone embedded in a complex signal?
- How fast can I perform these measurements?
- How accurate are the results?


# Presentation Overview

---

- Why use the frequency domain?
- FFT – a short introduction
- Frequency interpolation
- Improvements using windowing
- Error evaluation
- Amplitude/phase response measurements
- Demos

# Clean Single Tone Measurement


---



- Clean sine tone
- Easy to measure
- Clean tone spectrum

# Noisy Tone Measurement


Our signal



- Noisy signal
- Difficult to measure in the time domain
- Noisy signal spectrum
- Easier to measure


# Fast Fourier Transform (FFT) Fundamentals (Ideal Case)

---




- The tone frequency is an exact multiple of the frequency resolution (“hits a bin”)

# FFT Fundamentals (Realistic Case)




- The tone frequency is not a multiple of the frequency resolution

# Input Frequency Hits Exactly a Bin




- Only one bin is activated

# Input Frequency is +0.01 Bin “off”




- More bins are activated

# Input Frequency is +0.25 Bin "off"




# Input Frequency is +0.50 Bin "off"




- Highest side-lobes

# Input Frequency is +0.75 Bin “off”




- The Side lobe levels decrease

# Input Frequency is +1.00 Bin “off”



- Only one bin is activated

# The Envelope Function



Real top

Highest Bin = a

Next highest  
Bin = b

# The Mathematics

---

▪ Envelope function: 
$$E_{env} = \frac{\text{Sin}(\pi \cdot \text{bin})}{(\pi \cdot \text{bin})}$$

▪ Bin offset: 
$$\Delta \text{bin} = \pm \frac{b}{(a + b)}$$

▪ Real amplitude: 
$$\text{Amp} = a \cdot \frac{(\pi \cdot \Delta \text{bin})}{\text{Sin}(\pi \cdot \Delta \text{bin})}$$

# Demo

---

- Amplitude and frequency detection by  $\text{Sin}(x) / x$  interpolation

# Aliasing of the Side-Lobes





Highest Bin =  
Bin 4

Aliased Bin =  
"Negative Bin 4"

# Weighted Measurement

---



- Apply a Window to the signal



Hanning window — one period of  $(1 - \cos)$

# Weighted Spectrum Measurement

- Apply a Window to the Signal




# Rectangular and Hanning Windows




- Side lobes for Hanning Window are significantly lower than for Rectangular window

# Input Frequency Exactly Hits a Bin




- Three bins are activated

# Input Frequency is +0.25 Bin “off”




- More bins are activated

# Input Frequency is +0.50 Bin "off"




- Highest side-lobes

# Input Frequency is +0.75 Bin “off”



- The Side lobe levels decrease

# Input Frequency is +1.00 Bin “off”




- Only three bins activated

# The Mathematics for Hanning ...

---

- Envelope: 
$$\text{Env} = \frac{\text{Sin}(\pi \cdot \text{bin})}{(\pi \cdot \text{bin}) \cdot (1 - \text{bin}^2)}$$
- Bin Offset: 
$$\Delta\text{bin} = \pm \frac{(a - 2b)}{(a + b)}$$
- Amplitude: 
$$\text{Amp} = a \cdot \frac{(\pi \cdot \Delta\text{bin})}{\text{Sin}(\pi \cdot \Delta\text{bin})} \cdot (1 - \Delta\text{bin}^2)$$

# A LabVIEW Tool




- Tone detector LabVIEW virtual instrument (VI)

# Demo


---

- Amplitude and frequency detection using a Hanning Window (named after Von Hann)
- Real world demo using:
  - The NI-5411 **AR**bitrary Waveform Generator
  - The NI-5911 **FLEX**ible Resolution Oscilloscope

# Frequency Detection Resolution



# Amplitude Detection Resolution



# Phase Detection Resolution



# Conclusions

---

- Traditional counters resolve 10 digits in one second
- FFT techniques can do this in much less than 100 ms
- Another example of 10X for test
- Similar improvements apply to amplitude and phase

# Conclusions (Notes Page Only)

---

- Traditional Counters Resolve 10 digits in one second
- FFT Techniques can do this in much less than 100 ms
- Another example of 10X for test
- Similar improvements apply to Amplitude and Phase